





**TYPE A****TYPE B****TYPE C****TYPE D**

Works for all FRDM boards\*;  
also based on Arduino UNO (no PWM on J2/2) and Arduino MEGA (no INT on J1/4, SPI on J2/6/8/10/12)  
NOTE: The KE04Z has the MOSI and MISO pins swapped on J2/8/10

No KE04Z\*;  
also based on Arduino UNO (no PWM on J2/2) and Arduino MEGA (no INT on J1/4, SPI on J2/6/8/10/12)

KL02Z, KL03Z, KL05Z\*;  
also based on Arduino UNO (no PWM on J2/2) and Arduino MEGA (no INT on J1/4, SPI on J2/6/8/10/12)  
NOTE: Arduino do not connect to odd pins  
The KE04Z has the MOSI and MISO pins swapped on J2/8/10

No KE04Z, KL02Z, KL03Z, KL05Z\*;  
also based on Arduino UNO (no PWM on J2/2) and Arduino MEGA (no INT on J1/4, SPI on J2/6/8/10/12)  
NOTE: Arduino do not connect to odd pins